DSP511 Quick Installation Guide

Packing List

System Unit x 1	84W power adapter x 1

➢ **Do not try to apply power to the system if any damaged components.**

Dimensions

I/O Outlets
The following figures show I/O outlets on the DSP511.

> **Front View**

> **Rear View**

|			
1	12VDC power input	8	USB 3.2
2	USB 2.0	9	RS-232
3	4x HDMI	10	Clear EDID button
4	GbE LAN	11	Reset button
5	2.5GbE LAN	12	Power button
6	Audio jack (line_out/Mic_in)	13	Remote power switch
7	Device management port		

1 Installation of SODIMM Memory

Step 1 Turn off the system and unplug the power cord.
Step 2 Turn the system upside down to locate screw at the bottom then loosen one screw.

Step 3 Open the DRAM cover and locate the SO-DIMM socket on the board.

Step 4 Insert a gold-colored contact into the socket and push the module two end latches till locked of the DRAM.


Step 5 Put the DRAM cover and fasten one screw back into the system.

2 Installation of M.2 Device

Step 1 Turn off the system and unplug the power cord.
Step 2 Turn the system upside down to locate screws at the bottom then loosen all screws.

Step 3 Open the TOP cover , located the M.2 socket on main board.

Step 4 Identify the M.2 M Key slot, insert a SSD module into the socket and then fasten a screw.

Step 5 Put the TOP cover and fasten four screws back into the system.